

# Know-how is the difference



Enough power to compress strong springs on vehicles like Ducato, Jumper and Boxer.



Safety guard that also ensures an ergonomic work position.



Mobile. Easily moved between workstations. Ready for use in a matter of seconds.

## Spring compressor

Efficient, professional and safe dismantling and mounting of McPherson "struts"

"Universal swivel jaws that fit all springs. Only the spring holder needs to be replaced. Strong and reliable air pump. Strong enough for most vans, 4WD, SUV, etc.

### Accessories

929050



Strut vice.

## Compac CSC



*Long stroke of 330 mm.*

*Min. distance between jaws and spring holder down to just 40 mm.*

*Max. distance between jaws and spring holder up to 390 mm.*

*Suitable for conical springs.*

*Moveable arms for universal jaws ensure a precise and vertical pressure.*

### Standard



2 Spring holders (78 - 125 mm and 125 - 200 mm)  
Spring holders positioned on the side of the press. Positioned and in use in seconds.

*Ergonomically design and foot operated for "hands free" operation. Air connection required. 8 to 13 bar (Max!). Air consumption max. 225 litre pr. minut.*

See [www.compac.dk](http://www.compac.dk) for further information on the vehicles you are servicing.